Practical no. 4 FS19CO042

Aim: Install Network interface card and locate MAC address of computer

Required tools/components: PC with an empty PCI slot, Network Interface Card (NIC), Screw drivers

## Theory and steps:

#### • Network Interface Card (NIC)

A network interface card (NIC) is a hardware component without which a computer cannot be connected over a network. It is a circuit board installed in a computer that provides a dedicated network connection to the computer. It is also called network interface controller, network adapter or LAN adapter.

Every NIC card has a speed rating in terms of Mbps which determines max bandwidth.

Each NIC card has a unique unchangeable MAC addresses also known as physical network address.


#### Purpose:

- > NIC allows both wired and wireless communications.
- > NIC allows communications between computers connected via local area network (LAN) as well as communications over large-scale network through Internet Protocol (IP).
- > NIC is both a physical layer and a data link layer device, i.e. it provides the necessary hardware circuitry so that the physical layer processes and some data link layer processes can run on it.

#### Types of NIC cards:


- **Wireless** These are NICs that use an <u>antenna</u> to provide wireless reception through <u>radio frequency</u> waves. Wireless NICs are designed for Wi-Fi connection.
- Wired These are NICs that have input jacks made for cables. The most popular wired LAN technology is Ethernet.
- USB These are NICs that provide network connections through a device plugged into the USB port.
- **Fiber optics** These are expensive and more complex NICs that are used as a high-speed support system for network traffic handling on server computers. This could also be accomplished by combining multiple NICs.

### Image:




# • Installation process of Network Interface Card


- Read specifications of NIC and get acquainted with user guide available with NIC.
- Power off the PC, remove power cord and avoid any static charge.
- Remove side panel of PC case to expose motherboard so that PCI slots on motherboard are easily accessible.



• Ensure that there is at least one empty PCI slot and remove any slot insert if pre-installed.



- Carefully remove the network card from its static-proof plastic envelope, and slide it into the slot.
- Seat the card in the slot firmly with gentle pressure along the length of the card, especially right about the slot itself.




- Screw the card to computer frame avoiding overtightening.
- Close the computer case and connect ethernet cable to slot available on NIC.
- Plug PC and power it on. Go to Device manager and install appropriate drivers for the make and model of NIC. Troubleshoot the drivers and ensure the source is from a trusted supplier.
- Enjoy surfing the internet

## • Locate the MAC address of computer.

Every legit NIC card has a unique and immutable MAC address allocated by <u>IEEE (Institute of Electrical and Electronics Engineers)</u> giving every device a unique identity.

Steps to locate your PC's MAC address. (Windows OS demonstration)

> Start your PC or laptop and open Command prompt or Windows Powershell.



Type in the following command: ipconfig /all press enter.
Details of all network adapters/NICs will be displayed including their MAC address as physical address.

```
Command Prompt
                                                                             Microsoft Windows [Version 10.0.18363.1198]
(c) 2019 Microsoft Corporation. All rights reserved.
C:\Users\ADMIN>ipconfig /all
Windows IP Configuration
  Host Name . . . . . . . . . . . . . DESKTOP-A6ALB5L
  Primary Dns Suffix . . . . . . :
  IP Routing Enabled. . . . . . . : No
  WINS Proxy Enabled. . . . . . . . No
Ethernet adapter Ethernet 3:
  Connection-specific DNS Suffix .:
  Description
                                · VirtualRox Host-Only Ethernet Adapter
  Physical Address. . . . . . . . : 0A-00-27-00-00-10
  DHCP Enabled. . . . . . . . . . . . . No
Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . . : fe80::f9f4:7ed9:6cf2:3f84%16(Preferred)
  IPv4 Address. . . . . . . . . . . . . . . 192.168.56.1(Preferred)
  Default Gateway . . . . . . . :
  DNS Servers . . . . . . . . . : fec0:0:0:fffff::1%1
                                 fec0:0:0:ffff::2%1
                                 fec0:0:0:ffff::3%1
  NetBIOS over Tcpip. . . . . . : Enabled
Ethernet adapter Ethernet:
  Connection-specific DNS Suffix .:
  Description

    Realtek PCTe FF Family Controller

  DHCP Enabled. . . . . . . . . . . . Yes
Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . : fe80::95cc:4bfc:153e:a5bb%17(Preferred)
  IPv4 Address. . . . . . . . . . . . . . . . 192.168.0.103(Preferred)
  Lease Obtained. . . . . . . . : Saturday, December 26, 2020 11:11:42 AM
  Lease Expires . . . . . . . . . Saturday, December 26, 2020 2:11:42 PM
  Default Gateway . . . . . . . : 192.168.0.1
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-24-C5-DE-81-00-E0-4C-5C-00-0B
  DNS Servers . . . . . . . . . . . . . 8.8.8.8
  NetBIOS over Tcpip. . . . . . : Enabled
Ethernet adapter vEthernet (Default Switch):
  Connection-specific DNS Suffix .:
  Description
                                : Hyper-V Virtual Ethernet Adapter
  Physical Address. . . . . . . . : 00-15-5D-8F-DD-11
  DHCP Enabled. . . . . . . . . . . . . NO
Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . : fe80::d938:4573:6598:9e84%23(Preferred)
  IPv4 Address. . . . . . . . . . : 172.18.67.193(Preferred)
  Default Gateway . . . . . . . . :
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-24-C5-DE-81-00-E0-4C-5C-00-0B
  DNS Servers . . . . . . . . . : fec0:0:0:ffff::1%1
                                  fec0:0:0:ffff::2%1
                                  fec0:0:0:ffff::3%1
  NetBIOS over Tcpip. . . . . . : Enabled
C:\Users\ADMIN>
```

Conclusion: Thus we installed NIC card and located MAC address on computer.