

Aim: Connect computers using wireless media.

Tool used: Cisco Packet tracer student software.

Required components: Wireless router, PC, Laptop, Mobile, Tablet

Theory and steps:

- **Wireless Router**


A **wireless router** is a device that performs the functions of a router and also includes the functions of a wireless access point. It is used to provide access to the Internet or a private computer network. Depending on the manufacturer and model, it can function in a wired local area network, in a wireless-only LAN, or in a mixed wired and wireless network.

Wireless devices

For a device to connect to a wireless router, it must have wireless WiFi connectivity. Most of the mobiles, tablets and laptops have in-built WiFi connectivity. Many motherboards don't have WiFi pre-installed, hence a NIC or wireless adapter is required to connect wirelessly.


Steps for Connecting devices using wireless media are as follows:

1. From the wireless section of Devices, select Wireless router and place it on the canvas




2. Select and place desired end devices like PCs, laptops, etc


Devices with pre-installed WiFi auto connect the router, but generic PCs and laptops need to have NIC swapped by those which support wireless connectivity.



3. Configuring PC for wireless connection:


Click on a PC and navigate to Physical tab. Turn PC power off and drag existing network module to module tray on left:







Drag the WMP300N module from modules tray to empty module section of PC

Thus, module is swapped, now turn on the power and close PC window. PC will automatically connect to Wireless router after few seconds




4. Configuring laptops for wireless connectivity

Similar to PC, turn off power and swap the default module in laptops with WMP300N module. Again power on laptop




5. Similarly swap network modules of other laptops and PCs and after some time, all of them will be connected to router automatically.



6. Setting up static IP addresses (Optional)


By default every device is assigned a unique dynamic IP by router, we can set up unique static Open PC or laptop and under Desktop tab select click on IP configuration



Select Static IP and enter unique IP address for every device


Close the window

Similarly, allocate unique IP addresses to other devices too.




7. Checking connection by pinging other devices from command prompt


Click on any device and under desktop, click on Command prompt




Enter the following cmd: **ping <valid IP>** for example, ping 192.168.0.1
If the IP is valid, you'll see a successful reply message.




8. Checking connection by sending packets through Cisco packet tracer GUI
Select packet on right hand side toolbar




Click on source device to dispatch packet



Click on target device that receives packet



If the IP addresses and connections are properly configured, a Successful status is shown, similarly check connection across other devices



Conclusion: Thus, we connected computers and other devices using wireless media